

# Kore wheel arch covers complete the high-quality Kore linings package

Koskisen Germany  
Alexander Bechthold  
Manager, Kore Products  
+49 151 1117 8281  
[alexander.bechthold@koskisen.com](mailto:alexander.bechthold@koskisen.com)  
[kore@koskisen.com](mailto:kore@koskisen.com)

**Kore**<sup>™</sup>  
Easy solutions for your van.

# The Kore van solution would not be complete without the finishing touch of the wheel arch covers

Naturally, the covers protect the wheel arches from bumps and scrapes - but they also complement the whole van interior. Overall, the Kore wheel arch covers enhance the resale value of your van.

Wheel arch covers are available for the following van models:

- Volkswagen Caddy
- Volkswagen Caddy Maxi
- Volkswagen T5 WB 3000
- Volkswagen T5 WB 3400
- Volkswagen Crafter
- Mercedes-Benz Sprinter
- Mercedes-Benz Vito
- Fiat Ducato
- Fiat Scudo
- Peugeot Boxer
- Peugeot Expert
- Citroën Jumper
- Citroën Jumpy
- Renault Trafic
- Renault Master FWD
- Opel Vivaro
- Opel Movano FWD
- Nissan Primastar
- Nissan NV 400 FWD
- Ford Transit FWD

All Kore wheel arch covers are vacuum formed of HPDE plastic. The material is durable, adapts to low temperatures (up to  $-50\text{ c}^{\circ}$ ) and is also suitable for recycling.

How to install the wheel arch covers:

1. Place the covers over the wheel arches
2. Install the floor. The bottom of the wheel arch cover is securely held in place under the floor panel and requires no additional fastening
3. Install the side linings, the rear edge of the wheel arch cover sits behind the Kore side linings and is secured using the supplied fixings

**Easy to install**

**Strong and durable**

**Reduces noise level**

